

Download! for PC User Guide

Document version 1.1

NOKIA

Contents

1. Introduction to Download! for PC.....	3
1.1. Requirements.....	3
1.2. References.....	3
2. Installing Download! for PC.....	5
2.1. Before installation	5
2.2. Installing Download! for PC from a CD-ROM	5
2.3. Installing Download! for PC from a Web page	5
3. Getting Started with Download! for PC.....	7
3.1. Starting Download! for PC.....	7
3.2. Connecting your mobile device to the PC	7
3.2.1. Selecting the connection type	8
3.2.2. Connecting your mobile device via a cable	8
3.2.3. Connecting your mobile device via Bluetooth	9
3.2.3.1. Pairing your mobile device with the PC.....	9
3.2.4. Connecting your mobile device via infrared	10
3.3. Activating a mobile device.....	10
4. Downloading Content to the PC.....	12
4.1. Browsing add-on services and software for your mobile device and PC.....	12
4.2. Browsing content from catalogs	13
4.2.1. Browsing catalogs	13
4.2.2. Previewing content.....	13
4.2.3. Bookmarks (My favourites).....	13
4.3. Purchasing and downloading content	14
4.3.1. Purchase options	15
4.3.2. Payment methods.....	15
4.4. Viewing the status of the download	15
5. Managing Content.....	16
5.1. Viewing downloaded content	16
5.2. Copying content between the PC and your mobile device.....	16
5.2.1. Copying content from the PC to your mobile device.....	16
5.2.2. Copying content from your mobile device to the PC.....	17
5.3. Removing content	17
5.3.1. Removing content from the PC.....	17
5.3.2. Removing content from your mobile device	17
6. My Nokia	19
7. Guides and Manuals.....	20
7.1. Viewing guides and manuals.....	20
8. Upgrading Download! for PC	21
9. Safety Notes	22
Appendix A. Third-party Software License Agreements	24
Sharp Vector Graphics License	24

1. Introduction to Download! for PC

Download! for PC enables you to discover mobile content using a PC. When you connect your mobile device to the PC, Download! for PC automatically synchronises with the corresponding software on your device. This makes it easy for you to find, download and manage content that is compatible with your device.

1.1. Requirements

You need the following software and accessories to successfully install and use Download! for PC and to connect your mobile device to the PC.

Software or accessory	Needed for
Nokia PC Suite version 6.82 or newer, or Nokia Nseries PC Suite	Running Download! for PC
Windows XP Professional or Home Edition or Windows Vista	Installing and running Download! for PC
At least 100 MB of free disk space	Installing and running Download! for PC
At least 256 Mb of memory. However, 512 Mb is recommended.	Installing and running Download! for PC
Administrator rights	Installing Download! for PC
At least one of the following: <ul style="list-style-type: none"> ◆ USB connection cable (DKU-2, DKE-2, CA-53 or CA-70) and a compatible port on the PC ◆ Bluetooth wireless technology accessory and software ◆ Infrared port on the PC Note: Available Bluetooth technologies and their versions may not be supported by your Nokia mobile device. Check your Nokia device user guide for further details on compatible Bluetooth technologies.	Connecting your mobile device to the PC
Compatible mobile device with the Download! mobile application	Performing certain tasks with Download! for PC

To check which mobile device models are compatible with Download! for PC, go to www.nokia-asia.com/downloadpc.

Note: In this guide all references to a PC apply equally to a laptop computer.

Note: Use original Nokia cables with Download! for PC to ensure reliable operation of the application. Check the labelling on your cable.

Note: You should use the same language in Download! for PC, the PC operating system and your mobile device to ensure smooth operation of the application.

1.2. References

For more information about Download! for PC, see the following sources:

- ◆ Download! for PC help
- ◆ Download! for PC Web pages at www.nokia-asia.com/downloadpc

For more information on using Nokia PC Suite, see the following sources:

- ◆ Nokia PC Suite help
- ◆ User's Guide for Nokia PC Suite
- ◆ Nokia PC Suite Web pages at www.nokia-asia.com/pcsuite

For more information on using Nokia Nseries PC Suite, see the following sources:

- ◆ Nokia Nseries PC Suite help

For more information on using your mobile device, see the device's user guide.

2. Installing Download! for PC

You can install Download! for PC from a CD-ROM that is included in your mobile device's sales package or from the Download! Web page at www.nokia-asia.com/downloadpc. Note that you need administrator rights to the PC to be able to install software on it.

2.1. Before installation

Before installing Download! for PC, make sure that you have all the required software installed and accessories available (see Section 1.1, "Requirements"). If you know that you want to use a Bluetooth connection between the PC and your mobile device, you need Bluetooth wireless technology software on the PC.

Note: Installing and using Download! for PC requires version 6.82 of Nokia PC Suite (if you are not using Nokia Nseries PC Suite). If your Nokia PC Suite version is older, please update.

You need to have Download! version 3.1.50 in your mobile device to be able to use Download! for PC. If you do not have it, it is downloaded and installed on your device as part of the Download! for PC installation process. For more information on the process, see Section 2.2, "Installing Download! for PC from a CD-ROM", or Section 2.3. "Installing Download! for PC from a Web page".

To check the version of Download! on your mobile device:

1. Open Download! on your mobile device.
2. Select **Options > Application > About**.
3. Select **OK**.

2.2. Installing Download! for PC from a CD-ROM

If your mobile device's sales package contains a Download! for PC CD-ROM, you can use it to install the software on a PC. The installation is performed using either Nokia PC Suite or Nokia Nseries PC Suite installer (with Nokia Nseries devices).

To install Download! for PC from a CD-ROM:

1. Insert the CD-ROM into the CD-ROM drive of the PC.
2. Follow the on-screen instructions to install Download! for PC.

The installation process takes you to the Download! for PC Web site, www.nokia-asia.com/downloadpc, from where the software can be downloaded and installed. In addition, the process includes downloading the Download! mobile application version 3.1.50 and installing it on your mobile device if you do not have it installed already.

3. At the end of the installation, click **Finish**.

When the installation is complete, a special Download! start-up icon is added to the Nokia PC Suite or Nokia Nseries PC Suite launcher, depending on which one of these two is installed on your PC.

2.3. Installing Download! for PC from a Web page

You can install Download! for PC from a Web page. The installation is performed using either Nokia PC Suite or Nokia Nseries PC Suite installer (with Nokia Nseries devices). If you do not have the Download! mobile application version 3.1.50 installed on your mobile device, the installation process also downloads and installs this version onto your device.

To install Download! for PC from a Web page:

1. Open a Web browser.
2. Go to www.nokia-asia.com/downloadpc.
3. Start the installation process in the main view:
 - a) Select your mobile device from the device list.
 - b) Click **Download**.

OR

Start the installation process on the **Download!** tab:

- a) Click the **Download!** tab.
 - b) Click **Download**.
 - c) Select your mobile device from the device list.
4. Follow the step-by-step instructions.

When the installation is complete, a special Download! start-up icon is added to the Nokia PC Suite or Nokia Nseries PC Suite launcher, depending on which one of these two is installed on your PC.

3. Getting Started with Download! for PC


To be able to view content in Download! for PC, you need to connect a compatible mobile device to the PC and associate it with Download! for PC. After the first connection, you will always find your mobile device in the device drop-down list on the left side of the screen. You can later browse and download content with Download! for PC without connecting your mobile device to the PC. You just need to activate your device by selecting it from the device drop-down list. However, some tasks related to purchase or content management require a connection between your device and the PC.

You can add several mobile devices to the device list of Download! for PC by first connecting the devices and then associating them with Download! for PC.



Figure 1: Mobile device drop-down list above the device image and memory indicators

3.1. Starting Download! for PC

To open Download! for PC, click the Download! icon  in any of the following locations:

- ◆ Nokia PC Suite main view
- ◆ Nokia Nseries PC Suite main view
- ◆ PC desktop

3.2. Connecting your mobile device to the PC

Performing the following tasks with Download! for PC requires a connection between your mobile device and your PC:

- ◆ Using Download! for PC for the first time
- ◆ Purchasing content using the SMS payment method
- ◆ Purchasing content that is digitally protected
- ◆ Copying content between the PC and your mobile device
- ◆ Removing content from your mobile device

When your mobile device is connected to the PC and set as active in Download! for PC, you can see an image of the device and indicators of external and fixed memory. When the device is not connected, the image is dimmed.

Note: Most of the tasks performed with Download! for PC also require an active Internet connection.

3.2.1. Selecting the connection type

You can connect your mobile device to the PC by using any of the following:

- ◆ USB cable
- ◆ Bluetooth connection
- ◆ Infrared connection

The connection types that are actually available to you depend on your mobile device model and the PC, as it may be that they do not support all the connection types. To check which connection types are supported by your device, see the device's user guide.

Connection type	Details
USB cable	◆ A fast and reliable method with which to connect a mobile device to a PC and transfer data.
Bluetooth	◆ A wireless method with which to connect a mobile device to a PC within a fairly short range. ◆ The preferable distance between the mobile device and the PC is 10 metres (30 feet) at most.
Infrared	◆ A wireless method with which to connect a mobile device to a PC wirelessly within a short range. ◆ The preferable distance is one metre (three feet) at most. Note: Infrared is slower than the other two connection methods.

3.2.2. Connecting your mobile device via a cable

To connect your mobile device via a cable for the first time:

1. Click **Get Connected** below the mobile device image or select **Tools > Add new device**.
A window for selecting the connection method opens. This window opens automatically when you start **Download! for PC** for the first time.
2. In the window, select the USB cable connection by clicking the USB icon.
3. Click the arrow right to confirm the connection type selection.
4. Attach a USB cable between your mobile device and the PC.
5. In your mobile device, select **PC Suite** as the connection mode.
6. Click **Finish**.

When a connection between your mobile device and the PC has been created, your device is added to the list of mobile devices (see Figure 1) in **Download! for PC**. If no other device is set as active in **Download! for PC**, the application automatically sets your device as active and starts retrieving content. If you already have one mobile device active in **Download! for PC** when you connect another device, the previous one stays active. You need to set the new device active manually. For instructions on how to activate a device, see Section 3.3, "Activating a mobile device".

To connect your mobile device via a cable on subsequent times:

1. Attach a USB cable between your mobile device and the PC.
2. In your mobile device, select **PC Suite** as the connection mode.

3.2.3. Connecting your mobile device via Bluetooth

To connect your mobile device via Bluetooth for the first time:

1. Make sure that your mobile device is set visible to other devices via a Bluetooth connection.
2. Activate Bluetooth connectivity on your mobile device.
3. If you are activating Bluetooth connectivity for the first time on your mobile device, give a name to your device. This name is used to identify your device every time you pair it with a PC or another mobile device. The maximum length for the device name is 30 characters.
4. Make sure that Bluetooth connectivity is activated on the PC.
5. Click **Get Connected** below the mobile device image or select **Tools > Add new device**.
A window for selecting the connection method opens. This window opens automatically when you start Download! for PC for the first time.
6. In the window, select the Bluetooth connection by clicking the Bluetooth icon.
7. Click the arrow right to confirm the connection type selection.
Download! for PC starts to search for mobile devices with active Bluetooth connectivity within range of the PC.
8. Select your mobile device from the list and click the arrow right.
A window for authenticating your device opens.
9. Pair your mobile device with the PC. For detailed instructions, see Section 3.2.3.1, "Pairing your mobile device with the PC".
10. Click the arrow right again and then **Finish**.

When a connection between your mobile device and the PC has been created, your device is added to the list of mobile devices (see Figure 1) in Download! for PC. If no other device is set as active in Download! for PC, the application automatically sets your device as active and starts retrieving content. If you already have one mobile device active in Download! for PC when you connect another device, the previous one stays active. You need to set the new device active manually. For instructions on how to activate a device, see Section 3.3, "Activating a mobile device".

To connect your mobile device via Bluetooth on subsequent times:

1. Make sure that your mobile device is set visible to other devices via a Bluetooth connection.
2. Activate Bluetooth connectivity on your mobile device.
3. Make sure that Bluetooth connectivity is activated on the PC.


If you have paired your mobile device with the PC and set the PC authorised when connecting for the first time, you do not need to repeat the pairing again.

Note: To be able to connect your mobile device to the PC using a Bluetooth connection, you need a compatible Bluetooth stack on your PC. Check your Nokia mobile device user guide for further details about compatibility with different Bluetooth technologies.

3.2.3.1. Pairing your mobile device with the PC

To be able to use Bluetooth as the connection type, your mobile device needs to be paired with the PC. If this is the first time that you are connecting your device to the PC using a Bluetooth connection, Download! for PC guides you through the process of pairing. You only need to pair your device and the PC once if you also authorise the PC on the device side.

To pair your mobile device with the PC:

1. In the mobile device authentication window in Download! for PC, type a PIN code in the PIN code field.
2. In your mobile device, type the same PIN code when requested.
3. When PC Download! asks for a name for the mobile device, type the same name that has been defined in your device's Bluetooth application settings.
4. When your mobile device shows a query for accepting the connection, click **Yes**.
5. Authorise the PC in your mobile device:
 - a) Go to the paired devices view. The tab has the following symbol: .
 - b) Select the PC from the list of devices.
 - c) Using the **Options** menu, set the PC as trusted or authorised, depending on the terminology used in your mobile device.

Now the PC is authorised in your mobile device and you do not need to accept connections to the PC separately each time.

It is also possible to start the pairing process in your mobile device. For more information, see the device's user guide.

3.2.4. Connecting your mobile device via infrared

To connect your mobile device via infrared for the first time:

1. Click **Get Connected** below the mobile device image or select **Tools > Add new device**.
A window for selecting the connection method opens. This window opens automatically when you start Download! for PC for the first time.
2. In the window, select the infrared connection by clicking the infrared icon.
3. Click the arrow right to confirm the connection type selection.
4. Activate Infrared on your mobile device.
5. Place your mobile device so that its infrared port points at the infrared port of the PC.
6. Click **Finish**.

When a connection between your mobile device and the PC has been created, your device is added to the list of mobile devices (see Figure 1) in Download! for PC. If no other device is set as active in Download! for PC, the application automatically sets your device as active and starts retrieving content. If you already have one mobile device active in Download! for PC when you connect another device, the previous one stays active. You need to set the new device active manually. For instructions on how to activate a device, see Section 3.3, "Activating a mobile device".

To connect your mobile device via infrared on subsequent times:

1. Activate Infrared on your mobile device.
2. Place your mobile device so that its infrared port points at the infrared port of the PC.

3.3. Activating a mobile device

You can connect several mobile devices to Download! for PC, but only one device can be active at a time.

If you already have one mobile device active in Download! for PC when you connect another device, the previous one stays active. You need to set the new device active manually.

To set a mobile device active, select it from the mobile device drop-down list. When you change the active mobile device, the content offering in Download! for PC is automatically updated to be compatible with the newly activated device.

If there is no mobile device active when you connect another device to the PC, the connected device is automatically set active.

Note: You cannot change the active mobile device if there are ongoing actions in Download! for PC, such as synchronisation of the download history or file transfer between a device and the PC.

4. Downloading Content to the PC

With Download! for PC, you can download two types of content to the PC:

- ◆ Add-on software that complements your mobile device or PC: available in the Home view
- ◆ Catalog contents: available in Catalogs

In addition, you may find add-on services offered to your mobile device model in the Home view.

4.1. Browsing add-on services and software for your mobile device and PC

The Home view of Download! for PC shows services or software that you can download to complement the current functionality of your mobile device or PC. All the content is free of charge.

When you start Download! for PC, you are taken directly to the Home view. If you have navigated to other views and wish to return to the Home view, click the **Home** navigation button on the left or select **View > Go to > Home**.

In the list of add-on services and software, there may also be categories into which you need to browse to find the services or software.

To view the contents of a category, click the category icon or name. A list of the contents opens on the right. If there are subcategories, these are also listed on the left below the higher-level category icon. If all categories, services or software are not visible, scroll down the list to see the rest.

To navigate between categories, click the category icons or names on the left.

To get more information on an add-on service or software:

- ◆ At the top level of the Home view, click the icon or name of the service or software.
- ◆ Inside a category, click the icon of the service or software.

A details view opens on the right. In addition to product information, the view may also contain a preview option. For online services, the details view contains a **View** button. If you click this button, an external browser opens to the service.

To access add-on services, click **View** in any of the following locations:

- ◆ At the top level of the Home view
- ◆ Inside a category
- ◆ In a details view

Some software is intended only for mobile devices and some only for PC. You can see the type of the software as a small icon on top of the software icon. Online services have their own icons.




Figure: Icons for mobile content, PC content and an online service

For instructions on how to download add-on software, see Section 4.3, “Purchasing and downloading content”.

4.2. Browsing content from catalogs

Catalogs is a shopping mall where you can purchase and download content for your mobile device. Some of the content may be free of charge. In Catalogs you can browse different shops called catalogs, preview, purchase and download content, and create bookmarks to your favourite content categories.

To navigate into Catalogs, click the **Catalogs** navigation button on the left or select **View > Go to > Catalogs**.

4.2.1. Browsing catalogs

In the Catalogs main view you can see a list of catalogs on the left. If all the catalogs are not visible, scroll down the list to see the rest.

To view the contents of a catalog:

1. Click the catalog icon or name. A catalog disclaimer is displayed.
2. Accept the catalog disclaimer by clicking **Accept**. If you decline, the catalog contents are not shown.

The content categories of the catalog are listed on the left below the catalog icon. The list on the right shows the same categories with icons and action buttons.

To view the contents of a category, click the name of the category on the left or the icon of the category on the right. After this, the area on the right shows the contents. If there are subcategories, these are also listed on the left below the higher-level categories. You may need to navigate deeper to view actual downloadable content. If there is downloadable content in the category or subcategory, this content is listed on the right with icons, names and other information. If all categories or downloadable content are not visible, scroll down the list to see the rest.

To navigate between categories and subcategories, click the categories on the left.

To view content details, click the icon of the content. From the details view, you can purchase and possibly preview the content. If the content is free or charge, you can download it directly.

To check for content updates during the same Download! for PC session, select **Tools > Refresh content**.

Note: You can also access all the catalogs by clicking a catalog icon in the Home view on the lower right.

Note: If you have created a bookmark for a category, you can also view the category contents by clicking the bookmark in the Catalogs main view under **My favourites**.

4.2.2. Previewing content

For some content there may be a preview available. A preview for a game or application is typically an image. For a ring tone it is typically an audio clip.


To preview content:

1. Click **Preview** in the list of content or in the content details view. Download for PC! opens a preview window (if the preview is an image) or an external viewer (for example to play music).
2. Close the preview window or external viewer.

4.2.3. Bookmarks (My favourites)

You can create bookmarks for your favourite categories in a catalog. These bookmarks will be visible in the Catalogs main view, under **My favourites**. A bookmark has the category icon, name and description. When you click a bookmark, the contents of the category are shown.

To create a bookmark for a catalog category:


1. Navigate into the catalog.
2. Click the Add to favourites button  in the list of categories. A window opens for naming the bookmark.
3. If you wish to change the name suggested by Download! for PC, type a new name.
4. Click **OK**.

The bookmark is added into My favourites in the Catalogs main view.

You can later delete bookmarks that you have created.

4.3. Purchasing and downloading content

The add-on software that you can find in the Home view is free of charge. To download add-on software:

1. At the top level of the Home view, click the Download button  next to the software.
- OR
1. If you wish to see more information on the software before downloading, click the icon or name of the software in the Home view.
 2. In the details view, click **Download**.
- OR
1. Inside a category, click **Download** next to the name of the software.
- OR
1. If the software is located in a category and you wish to see more information on the software before downloading, click the software icon in the category.
 2. In the details view, click **Download**.

Catalogs may contain both free content and content that needs to be purchased. You can see the price of downloadable content next to the name and type description in the list of contents as well as in the content details view.

You may be able to select between several purchase options and payment methods when you purchase content. For more information on purchase options, see Section 4.3.1, "Purchase options". For more information on payment methods, see Section 4.3.2, "Payment methods".

If the catalog content is free of charge, you can download it directly:

1. In the list of content, click **Download** next to the name and content type description.
- OR
1. If you wish to see more information on the content before downloading, click the icon in the list of content.
 2. In the details view, click **Download**.

If a price has been given to the content, you need to purchase it before downloading:

1. Click **Buy** in the list of contents next to the content price information or in the content details view.

2. If there are several purchase options available, a view opens with content details and a list of available purchase options. Select the suitable purchase option and click **Next**.
A view opens with a list of available payment methods.
3. Select the suitable payment method. More information on the selected method is shown.
4. With some payment methods, such as credit card payment, the purchase requires more details. Fill in the requested details in the form that is shown.
5. Click **Next**.
A confirmation view opens with payment details.
6. To confirm the payment, click **Next**.

The content download starts automatically after a successful purchase. You can view the status of the download in the Download status panel on the lower right corner. When the download is complete, you are encouraged to copy the content to your mobile device. You can also copy it later in the My Downloads view. For more information, see Section 5.2, "Copying content between the PC and your mobile device".

Note: All the payment information that you give is transferred through a SSL secured connection.

4.3.1. Purchase options

You may be able to select between several purchase options (or licence types) when you purchase content. This means that there are different prices defined for the content based on how you can use it. For example, you may be able to use an application for a trial period for a lower price.

4.3.2. Payment methods


You may be able to select between several payment methods when you purchase content. For example, you may see the following options:

- ◆ Premium SMS
- ◆ Credit card
- ◆ User account

When you purchase content with a credit card, you need to fill in your credit card details when they are requested. When you purchase content using a special user account, you need to give your authentication details.

4.4. Viewing the status of the download

Download! for PC starts to download content automatically after you have purchased it (chargeable content) or clicked to download it (free content). Whether you are downloading add-on software or content from a catalog, you can view the status of the download in the Download status panel on the lower right corner.

You can cancel a content download by clicking the Cancel button .

5. Managing Content

You can manage content that you have downloaded by navigating into My Downloads. To navigate into My Downloads, click the **My Downloads** navigation button on the left or select **View > Go to > My Downloads**.

You can manage downloaded content in the following ways:

- ◆ View a list of content that you have downloaded with Download! for PC or with your mobile device.
- ◆ Copy content from the PC to your mobile device.
- ◆ Copy content from your mobile device to the PC.
- ◆ Remove content from your mobile device.
- ◆ Remove content from the PC (only content that has been downloaded using Download! for PC).

5.1. Viewing downloaded content

To view a list of content you have downloaded, click the **Download history** tab in My Downloads. This download history contains both content you have downloaded using Download! for PC and content you have downloaded with your mobile device. The history is automatically synchronised with your mobile device.

Note: If you download content using the Download! application in your mobile device while it is connected to the PC, you can select **Tools > Refresh content** to synchronise the download history of Download! for PC with that in your mobile device.

You can filter the download history according to content name, file size, type, price, method of download (PC or mobile) and date of download.

To see more information on downloaded content, click the desired content in the list.

If you have purchased content and later removed it from the PC, a button for downloading the content again is shown.

To view a list of content that you have downloaded and that is intended only for PC, click the **PC content** tab in My Downloads. You can filter the list of PC content according to name, file size and content type.

5.2. Copying content between the PC and your mobile device

To copy downloaded content between the PC and your mobile device, click the **Mobile content** tab in My Downloads. On this tab you can copy content in both directions: from the PC to your mobile device and from your mobile device to the PC.

Note: To copy content between the PC and your mobile device, you need to have your device connected to the PC.

Note: To select content that you wish to copy, select the check box next to the name of the content.

5.2.1. Copying content from the PC to your mobile device

To copy content from the PC to your mobile device:

1. In the list under **PC**, select the content you wish to copy to your mobile device. You can select several items.


2. Click the arrow left .

On the Mobile content tab, you can also see a list of content that you have downloaded to the PC but not yet copied to your mobile device. Unless the list is empty, a notification is also shown in the Notifications panel at the bottom of the screen, saying that you have *n* items to copy to your device. If you click the arrow next to such a notification, the Mobile content tab opens.

To remove a notification, click **Remove notification** next to the content.

5.2.2. Copying content from your mobile device to the PC

To copy content from your mobile device to the PC:

1. In the list under **Mobile**, select the content you wish to copy to the PC. You can select several items.
2. Click the arrow right .

Note: If you download content using the Download! application in your mobile device while it is connected to the PC, you can select **Tools > Refresh content** to synchronise the download history of Download! for PC with that in your mobile device. This updates the list of content shown on the Mobile content tab.

5.3. Removing content

In My Downloads, you can also remove downloaded content from the PC or your mobile device.

Note: To select content that you wish to remove when in the Mobile content tab, select the check box next to the name of the content.

5.3.1. Removing content from the PC

To remove content from the PC:

1. Click the **PC content** or **Mobile content** tab. You can also select several items.
2. Select the content you wish to remove.
3. Click **Delete** or the Delete button.
A confirmation view opens.
4. Click **Yes** to confirm the removal.

You can only remove content that you have downloaded using Download!, not other content stored on the PC.

5.3.2. Removing content from your mobile device

To remove content from your mobile device:

1. Click the **Mobile content** tab. You can also select several items.
2. Select the content you wish to remove.
3. Click the Delete button.
A confirmation view opens.

4. Click **Yes** to confirm the removal.

6. My Nokia

In the My Nokia view you can access the external My Nokia service that is related to your mobile device. To navigate into My Nokia, click the **My Nokia** navigation button on the left or select **View > Go to > My Nokia**.

You can also access My Nokia from the upper right corner of the Home view.

Note: The My Nokia service may not be available in your country. In this case, you can access the Nokia support services instead.

7. Guides and Manuals

In the Guides and Manuals view, you can find manuals related to your mobile device. To navigate into Guides and Manuals, click the **Guides & Manuals** navigation button on the left or select **View > Go to > Guides & Manuals**.

7.1. Viewing guides and manuals

When you activate your mobile device and receive content optimised for it, guides and manuals related to the device are downloaded to Download! for PC in the background. This download requires that you have an active Internet connection. Once a guide or manual has been downloaded, you can view it without an Internet connection.

To view a guide or manual:

1. Click **View** next to the name of the guide or manual.
An external reader application opens, showing the guide or manual.
2. To return to the Guides and Manuals view, close the external reader or activate the Download! for PC window.

If a newer version is available on a guide or manual, an **Update** button is shown. Click **Update** to view this new version. You need an active Internet connection.

Note: Typically, the tool you need for viewing a guide or manual is Adobe Reader.

8. Upgrading Download! for PC

If a new version of Download! for PC is available, you can see a notification about this in the Notification panel at the bottom of the screen.

To update Download! for PC:

1. Click the arrow button next to the notification.

The software update is downloaded to the PC. A notification is shown, informing you that Download! for PC needs to be closed for updating the software.

2. To accept the update, click OK.

Download! for PC is closed and the new version of the software is installed on the PC. After this, the updated version of Download! for PC opens.

If you decline the update, the new version of the software is kept on the PC and installed automatically the next time you start Download! for PC.

Note: If you have a Nokia Nseries device, Download! for PC updates will be delivered and installed automatically via Nokia Nseries Update Manager, without notifications.

9. Safety Notes

Important safety notes

All the safety instructions in the user's guides of your mobile device and PC also apply when this product is used with the mobile device.

Remember to make backup copies of all important data to protect against possible loss or alteration.

Legal Notice

Copyright © 2007 Nokia. All rights reserved.

Reproduction, transfer, distribution or storage of part or all of the contents in this document in any form without the prior written permission of Nokia is prohibited.

Nokia, Nokia PC Suite, Nokia Nseries PC Suite and Nokia Download! are registered trademarks of Nokia Corporation.

This application contains software licensed from third-party companies. For licenses, see Appendix A.



Java is a trademark of Sun Microsystems, Inc.

Other product and company names mentioned herein may be trademarks or tradenames of their respective owners.

The information in this document was written for Nokia Download! for PC 2.0. Nokia operates a policy of ongoing development. Nokia reserves the right to make changes and improvements to any of the products described in this document without prior notice.

Under no circumstances shall Nokia be responsible for any loss of data or income or any special, incidental, consequential or indirect damages howsoever caused.

The contents of this document are provided "as is". Except as required by applicable law, no warranties of any kind, either express or implied, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose, are made in relation to the accuracy, reliability or contents of this document. Nokia reserves the right to revise this document or withdraw it at any time without prior notice.

When the application is used, the content is downloaded through the user's Internet connection.

The user is solely responsible for choosing the Internet connection provider and the payment for such services, and Nokia shall not take any responsibility of it, including but not limited to its functions, availability or the basis of payment.

The initial connection between the user's mobile device and a PC is a mandatory requirement for the use of this application.

The connection between the user's mobile device and a PC is always needed when transferring the downloaded content to the mobile device.

Connection methods between the user's mobile device and a PC are limited to BlueTooth, IrDa and a compatible USB cable. A list of compatible connection methods can be found from www.nokia-asia.com/pcsuite and the methods may change from time to time.

Appendix A. Third-party Software License Agreements

Sharp Vector Graphics License

Copyright (c) 2002-2003, The Sharp Vector Graphics project (<http://sourceforge.net/projects/svgdomcsharp>)

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution. Neither the name of the Sharp Vector Graphics project nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.